

Step 3: apply adhesive to base

Step 4: position KH base and engage mechanical fastener





Finished application

